

(I) **ATTENZIONE!**

Togliere la corrente prima di eseguire qualsiasi collegamento elettrico o sostituire le lampadine.

- 1) Fissare a soffitto il supporto **A**; infilare il pezzo **B** ed eseguire il collegamento elettrico alla linea elettrica di alimentazione.
- 2) Infilare il disco metallico **C** e fissarlo con il dado **D** e la relativa rondella antirotazione; infilare il manicotto **E**, il disco metallico **G** e fissare il tutto con il dado **H** e la relativa rondella antirotazione.
- 3) Fissare le foglie **1** e **2** con le borchie **F**.
- 4) Montare tutte le foglie **3** seguendo al numerazione prefissandole con le borchie **I** e solo dopo bloccarle.
- 5) Avvitare la rondella **L** poi infilare il piatto in vetro **4** sostenendolo con la rondella **M**. Avvitare il pezzo in vetro **5**.

1

(GB) **WARNING!**

Switch off the current before connecting or relamping.

- 1) Hook the support **A** to the ceiling, slip the metal piece **B** and make up the electric connection to main feed line.
- 2) Slip the metal disk **C** and fix it with the nut **D** with its anti-rotation washer; slip the sleeve **E**, the metal disk **G** and fasten them by the nut **H** with its anti-rotation washer.
- 3) Fix the leaves **1** and **2** with the studs **F**.
- 4) Mount all the leaves **3** without tightening the studs following the numbers and only after that lock the studs.
- 5) Screw the washer **L**, then slip up the glass plate and hold it with the washer **M**. Screw the glass piece **5**.


1

(USA) **WARNING!**

Switch off the current before connecting or relamping. Do not attach to outlet box. The chandelier weight is more than 50 pounds (22.7 Kg)

- 1) Fasten the support **A** over the outlet box, slip the metal piece **B** and make up the electric connection to main feed line.(see circuit diagram)
- 2) Slip the metal disk **C** and fix it with the nut **D** with its anti-rotation washer; slip the sleeve **E**, the metal disk **G** and fasten them by the nut **H** with its anti-rotation washer.
- 3) Fix the leaves **1** and **2** with the studs **F**.
- 4) Mount all the leaves **3** without tightening the studs following the numbers and only after that lock the studs.
- 5) Screw the washer **L**, then slip up the glass plate and hold it with the washer **M**. Screw the glass piece **5**.

*The electric connections
to main feed line should
be made by qualified
electrician.*



Plafoniera/Ceiling lamp EXCELSIOR

r 5427/CR
r 5427/GR
r 5427/OR

h./Height cm 38 – 15”
Ø/Diameter cm 120 – 47”^{1/4}
Peso/Weight Kg 63 – 138½ lbs
r 120V **r** 230V
50Hz ~ 60Hz
N°10 x max. 60W
r E27 **r** E26
N°4 x max. 40W
r E14 **r** E12
Cl. I

